

LAЕ

Техническая информация (eng)

Контроллеры компрессора

MS-27

По вопросам продаж и поддержки обращайтесь:

Архангельск (8182)63-90-72
Астана (7172)727-132
Астрахань (8512)99-46-04
Барнаул (3852)73-04-60
Белгород (4722)40-23-64
Брянск (4832)59-03-52
Владивосток (423)249-28-31
Волгоград (844)278-03-48
Вологда (8172)26-41-59
Воронеж (473)204-51-73
Екатеринбург (343)384-55-89

Иваново (4932)77-34-06
Ижевск (3412)26-03-58
Казань (843)206-01-48
Калининград (4012)72-03-81
Калуга (4842)92-23-67
Кемерово (3842)65-04-62
Киров (8332)68-02-04
Краснодар (861)203-40-90
Красноярск (391)204-63-61
Курск (4712)77-13-04
Липецк (4742)52-20-81

Магнитогорск (3519)55-03-13
Москва (495)268-04-70
Мурманск (8152)59-64-93
Набережные Челны (8552)20-53-41
Нижний Новгород (831)429-08-12
Новокузнецк (3843)20-46-81
Новосибирск (383)227-86-73
Омск (3812)21-46-40
Орел (4862)44-53-42
Оренбург (3532)37-68-04
Пенза (8412)22-31-16

Пермь (342)205-81-47
Ростов-на-Дону (863)308-18-15
Рязань (4912)46-61-64
Самара (846)206-03-16
Санкт-Петербург (812)309-46-40
Саратов (845)249-38-78
Севастополь (8692)22-31-93
Симферополь (3652)67-13-56
Смоленск (4812)29-41-54
Сочи (862)225-72-31
Ставрополь (8652)20-65-13

Сургут (3462)77-98-35
Тверь (4822)63-31-35
Томск (3822)98-41-53
Тула (4872)74-02-29
Тюмень (3452)66-21-18
Ульяновск (8422)24-23-59
Уфа (347)229-48-12
Хабаровск (4212)92-98-04
Челябинск (351)202-03-61
Череповец (8202)49-02-64
Ярославль (4852)69-52-93

www.lae.nt-rt.ru || ecr@nt-rt.ru

MS-27

71x97x61 mm



Multi-compressor or multi-fan controller

Main Features

- Four ON/OFF outputs for the control of single or multi-stage compressors or fans.
- Proportional output for speed control (inverters).
- Output with change-over contacts for alarm control.
- Input for pressure transmitter (0/4...20mA) or for a temperature probe (NTC10K).
- Two digital inputs on voltage free contact for programmable function, up to three digital optocoupled voltage inputs for a complete system diagnostics.
- Selection of the control algorithm: rotation of outputs, sequential activation, optimisation of the available power.
- Pressure – Temperature conversion according to gas used.
- Storage of the latest nine alarms
- Automatic maintenance management.
- 115Vac or 230Vac power supply by means of built-in transformer.
- Connections on screw terminals or quick connectors.
- DIN-Rail mount.
- Connection to supervisory PC.

Applications

for cryogenerators in supermarkets, cold stores and all cryogenic systems with variable demand.




Technical Data

PRESSURE INPUT	TYPE:	0/4...20mA (LAE PGT35)
	RANGE:	-1.0...45.0BAR
	RESOLUTION:	0.1BAR
	ACCURACY:	±0.2BAR
TEMPERATURE INPUT	TYPE:	NTC10K (LAE SN4...)
	RANGE:	-50.0...120.0°C
	RESOLUTION:	0.5°C
	ACCURACY:	±0.5°C
POWER SUPPLY	MS27...E	230VAC±10%, 50/60Hz, 3W
	MS27...U	115VAC±10%, 50/60Hz, 3W
RELAY OUTPUTS	OUT1...OUT4	5(1)A
	ALARM	7(2)A
FRONT PROTECTION		IP55

MS27 series

Functions	-1QE-B	-1SE-A	-1SU-B
Connections	Screw terminals	✓	✓
	Quick on M/F terminals	✓	
Power supply	230Vac	✓	
	115Vac		✓
Serial port	TTL	✓	
	RS485	✓	✓

In order to know more options available for the models, please consult LAE or our local dealer.



По вопросам продаж и поддержки обращайтесь:

Архангельск (8182)63-90-72	Иваново (4932)77-34-06	Магнитогорск (3519)55-03-13	Пермь (342)205-81-47	Сургут (3462)77-98-35
Астана (7172)727-132	Ижевск (3412)26-03-58	Москва (495)268-04-70	Ростов-на-Дону (863)308-18-15	Тверь (4822)63-31-35
Астрахань (8512)99-46-04	Казань (843)206-01-48	Мурманск (8152)59-64-93	Рязань (4912)46-61-64	Томск (3822)98-41-53
Барнаул (3852)73-04-60	Калининград (4012)72-03-81	Набережные Челны(8552)20-53-41	Самара (846)206-03-16	Тула (4872)74-02-29
Белгород (4722)40-23-64	Калуга (4842)92-23-67	Нижний Новгород (831)429-08-12	Санкт-Петербург (812)309-46-40	Тюмень (3452)66-21-18
Брянск (4832)59-03-52	Кемерово (3842)65-04-62	Новокузнецк (3843)20-46-81	Саратов (845)249-38-78	Ульяновск (8422)24-23-59
Владивосток (423)249-28-31	Киров (8332)68-02-04	Новосибирск (383)227-86-73	Севастополь (8692)22-31-93	Уфа (347)229-48-12
Волгоград (844)278-03-48	Краснодар (861)203-40-90	Омск (3812)21-46-40	Симферополь (3652)67-13-56	Хабаровск (4212)92-98-04
Вологда (8172)26-41-59	Красноярск (391)204-63-61	Орел (4862)44-53-42	Смоленск (4812)29-41-54	Челябинск (351)202-03-61
Воронеж (473)204-51-73	Курск (4712)77-13-04	Оренбург (3532)37-68-04	Сочи (862)225-72-31	Череповец (8202)49-02-64
Екатеринбург (343)384-55-89	Липецк (4742)52-20-81	Пенза (8412)22-31-16	Ставрополь (8652)20-65-13	Ярославль (4852)69-52-93